snapmaker | Quick Start Guide



Content



Before You Start



Assemble the 3D Printer




Use the 3D Printer

Load Filament Level the Heated Bed Start Printing Support

Before You Start

Get the Screwdriver Ready

The screwdriver is dual-purpose. Change the blade as you need.



Used Symbols

Caution

Ignoring this type of message might result in malfunction or damage of the machine.

Notice

Details you should be aware of throughout the process.


- Ž. Tips

Tips offer you convenient operations and additional options.





Make sure that the highlighted part is facing the right way.

M4 x 8 Screw





Attach the Feet to the Base Plate















M4 x 8 Screw




3-in-1 3D Printer Quick Start Guide


Assemble the 3D Printer




Attach the Z Axis to the Base Plate



х 1



M4 x 8 Screw




Assemble the Screen Holder and then Slide the Touch Screen into the Screen Holder




Screen Holder


Touch Screen x 1







Linear Module $\times 1$






Attach the 3D Printing Module to the X Axis

.


M4 x 8 Screw x 4







Attach the Controller to the Z Axis





Assemble the 3D Printer Attach Filament Holder to the Z Axis 9 M4 x 28 Screw х2 Õ 000000 P Filament Holder х 1 10 A BANDE 0



Connect the Modules to the Controller and Power On


• • • • • •






Power Adapter x 1

The RJ25 Cable (Heated Bed Cable) is comparatively smaller than the RJ45 Cable (Module Cable).




Notice



You can also connect the cables according to the provided card.


Caution

Make sure all the cables are correctly and properly connected as illustrated before you power on the machine.





Do **NOT** connect or disconnect the cables or USB when the machine is powered on.

Use the 3D Printer











This Section Makes Sure the Heated Bed and X Axis





If the print cannot stick to the heated bed, it is recommended to go through this section again.



To level the heated bed, please level the four corners in order. These corners correspond to the numbers on the Touch Screen as shown in the next step.







3












On the Touch Screen, go to Settings > Calibration. It may take a few seconds after you tap Calibration. Tap 1 and the 3D Printing Module will move to the first corner.




Level the Heated Bed



Adjust the Distance Between the Heated Bed and the Nozzle








Adjust the distance between the Heated Bed and the nozzle using the Up and Down buttons. Keep adjusting until there is slight resistance on the paper from the nozzle. Use the Move 0.05 mm/0.2 mm/0.5 mm buttons to decide how far the nozzle moves every time you tap the Up or Down button. Level the Heated Bed



Use the Paper to Adjust the Distance




Level the Heated Bed



Level the Second to Fourth Corner


Tap 2 and follow steps 5-6 to level the second corner. Use the same method to level the third and fourth corners.






















When all the corners are leveled, tap Save. Remember to pull out the paper when you finish leveling.

Reset the Calibration to Factory Settings






After you detach and reattach the heated bed to the Y axis, use the **Reset** button to reset the calibration to factory default settings. It avoids the nozzle from digging into the heated bed during calibration by moving the nozzle about 3 mm above the heated bed.

Load Filament



Reposition the 3D Printing Module




tapping X+/Z+ until the 3D Printing Module is moved to the illustrated position.










On the Touch Screen, go to Controls > Change Filament > Confirm.





Change the Target Temperature Based on the Filament



🖌 Back		
Target Temp	200 °C	
Current Temp	60 ℃	
Temp -10 ℃	Temp +10 ℃	

Tap Temp -10°C/Temp +10°C to change the target temperature to the value you need. For example, if you want to print ABS, you need to change Target Temp to 240°C.


Then wait for the current temperature to gradually increase to the target temperature.

Load Filament












When you are waiting, hang the filament over the Filament Holder. For smoother printing, the end of the filament should be placed as shown above.




When the Current Temp reaches the Target Temp, press the button on the front of the 3D Printing Module and at the same time insert the filament into the hole on the top.













Keep inserting the filament until you see some filament coming out of the nozzle.








Use the provided Tweezer to clean the filament on the nozzle and tap **Back**.

Start Printing

We only provide a general description of the setup procedure in this guide. Please refer to the online manual for details: manual.snapmaker.com/3d_printing/





Download Snapmaker3D

Generate G-code

Choose a Way to Print










Download Snapmaker3D from our official website: snapmaker.com/download Start Printing






Follow our Thingiverse official account to find some useful models to print:

Generate G-code of the file you want to print.






Option 1

3

Using the Computer

(The computer must be connected to the machine throughout the process.)



Option 2

Using the USB Disk

(No need to connect your computer to the machine.)



Support

Besides this guide, there is also a User Manual available on our website: snapmaker.com/document Find the answers in our FAQ page if you run into any problem during assembly: faq.snapmaker.com Share anything you want with other Snapmaker users at our forum: forum.snapmaker.com

Any news from you is good news for us. If you have any questions, don't hesitate to contact us. We are here for you whenever you need general information, technical support or have any sales inquiries.

General Info@snapmaker.com Support support@snapmaker.com Marketing sales@snapmaker.com

See more fun stuff at:





Thomas Edison once said, "A minor invention every ten days, and a big one every six months or so." What is your first invention with the Snapmaker?

To use the laser engraver and CNC carver, please read the corresponding guide.

Part No.: FA001 V1.0.1